



Design & Manufacturing Excellence

Since 2004, Sunsquare Limited have been pioneering skylight designs, always aiming for the highest possible specification. By choosing Sunsquare to fulfill your skylight needs you can be safe in the knowledge that each product has been designed truly for its purpose; refined through rigorous prototyping, manufactured in-house in the UK and offered with a full warranty.



Testing & Certification

Sunsquare are the first skylight manufacturer in the world to have been awarded a BSI Kitemark™ for their entire range.

Over a two year period rigorous laboratory testing was undertaken to assess the safety, weather tightness, air permeability and wind resistance, with standards being surpassed by quite some margin.



Believing in Better

At Sunsquare we believe in better, appreciating that our entire business and reputation is reliant on our ability to design effective products; because a good design makes good products and a good product makes a good business.

We hope that your experience of Sunsquare proves to be a positive one and we thank you for your custom.



Designed & Manufactured in Suffolk, England



Sunsquare Limited

Kempson Way
Bury St Edmunds
Suffolk IP32 7AR
Tel. 01284 723377




FM597286

AERO ELEC ACCESS INSTALLATION MANUAL



sunsquare.co.uk






Step One :
Check the pre-installed upstand dimensions prior to lifting the skylight onto the roof area.

It is important to confirm that the upstand is square. This is achieved by comparing measurements taken across the diagonally opposite corners. If the upstand is square these dimensions will be the same.


Step Two :
Make sure that the top face of the upstand is clean, dry and free from undulations. Apply the skylight bedding tape (supplied) to the full perimeter of the upstand, along the outer edge.

Press the tape down firmly with your fingers to confirm full adhesion.



Step Four :
Carefully adjust the position of the skylight making sure it is correctly centred over the aperture.

Before moving onto the next step it is advisable to check the positioning of the skylight from the inside, as this will allow for easy fixing of the internal finishes.




Step Three :
Carefully lower the Aero Elec Access skylight onto the upstand, being careful not to trap your fingers between the upstand and skylight frame.

Check that the skylight is sat soundly onto the upstand, the frame should be continuously supported on all sides.



Step Five :
It is important that immediately after this step you move immediately onto step six. If this is not possible, leave the installation process here until such time as this can be achieved.

Referring to the supplied wiring and electronics manual, motorise the skylight to its fully open position. (While performing this action it is advisable to have someone remain on the roof to ensure that the skylight is secure during the movement cycle.)





Step Six :
Using the supplied screws fasten the skylight to the upstand through the pre-drilled holes.

Be careful not to over-tighten these screws as you risk damaging the frame.

Step Seven :
Attach the internal actuation cover profiles.

To achieve this lift the cover profiles from the inside of the skylight and align with the stainless steel fixing tabs. Pushing the profiles tightly against the fixing tabs, slide the cover profiles down to engage the lugs into the rear of the profile.

You are now able to motorise the skylight into the fully closed position.




Step Eight :
This completes the installation of the Sunsquare Aero Elec Access skylight. You are now able to remove all protective films for disposal.

Thoroughly clean the newly installed skylight using a proprietary glass cleaner and a soft lint free cloth.

IMPORTANT NOTE:
TO SUCCESSFULLY COMPLETE THIS INSTALLATION YOU ARE ADVISED TO UTILISE A MINIMUM OF TWO OPERATIVES. (SKYLIGHTS ARE HEAVY - TAKE CARE WHILE HANDLING)

YOU WILL REQUIRE THE FOLLOWING TOOLS:

- CORDLESS DRILL / DRIVER
- TAPE MEASURE
- T40 DRIVER BIT
- WIRING & ELECTRONICS MANUAL



Sunsquare take Health & Safety very seriously and we would recommend you protect yourself while installing your skylight by wearing safety boots, goggles and gloves...



If you experience any difficulty while installing your skylight, please contact our technical team for help by phone on 01 284 73377